Panasonic

5.8 GHz Expandable Cordless Phone System



Model shown is KX-TG5200.

Operating Instructions

Model No. KX-TG5200
KX-TG5202

Pulse-or-tone dialing capability

The unit is Caller ID compatible. To display the Caller's name and phone number, you must subscribe to Caller ID service.

PLEASE READ BEFORE USE AND SAVE.

Charge the battery for 6 hours before initial use.

Panasonic World Wide Web address: http://www.panasonic.com
for customers in the USA or Puerto Rico

Thank you for purchasing your new Panasonic cordless telephone.

Please read the IMPORTANT SAFETY INSTRUCTIONS on page 65 before use. Read and understand all instructions.

Caller ID, Call Waiting and Voice Mail Service, where available, are telephone company services. After subscribing to Caller ID this phone will display a caller's name and phone number. Call Waiting Caller ID, which displays a second caller's name and phone number while the user is on another call, requires a subscription to both Caller ID and Call Waiting with Caller ID Services (CWID). After subscribing to Voice Mail Service, this unit will give you visual indication to let you know when there are messages in the mailbox.

Attach your purchase receipt here.

Trademarks:

openLCR, openLCR.com, and the openLCR logo are the trademarks of openLCR.com, Inc.

Accessories (included)

For extra orders, call 1-800-332-5368.
For hearing or speech impaired TTY users, call 1-866-605-1277.

☐ AC Adaptor (p. 10) Order No. PQLV1Z (PQLV1)  one	☐ Telephone Line Cord (p. 10) Order No. PQJA10075Z one	☐ Wall Mounting Adaptor (p. 48) Order No. PQKL10063Z1  one
☐ Handset Cover (p. 11) Order No. PQKK10142Z1 KX-TG5200: one KX-TG5202: two	☐ Battery (p. 11) Order No. HHR-P104  KX-TG5200: one KX-TG5202: two	☐ Belt Clip (p. 47) Order No. PQKE10377Z1  KX-TG5200: one KX-TG5202: two
☐ Charger Unit (p. 10) (KX-TG5202 only) Order No. PQLV30024ZM AC Adaptor Order No. KX-TCA1-G (KX-TCA1)  one		

Expanding Your Phone

For KX-TG5200 users

KX-TG5200 includes one handset and one base unit. You can expand the system by adding up to 3 accessory handsets, sold separately.
A maximum of 4 handsets can be registered to the base unit.



- The included handset is pre-registered at the factory and assigned the extension number 1.

For KX-TG5202 users

KX-TG5202 includes two handsets, one charger unit and one base unit. You can expand the system by adding up to 2 accessory handsets, sold separately.
A maximum of 4 handsets can be registered to the base unit.



- The included handset is pre-registered at the factory and assigned the extension numbers 1 and 2.

The model numbers of the accessory handsets are KX-TGA520 and KX-TGA523. A charger is included with each accessory handset.
To order, contact your dealer or call 1-800-211-PANA(7262) to locate a dealer.

After purchasing accessory handsets, you must register each to the base unit. (Please read the accessory handset's Installation Manual.)

Contents

Preparation

For Best Performance 6

Location of Controls 7

Display 9

Installation 10

Connections 10

Installing the Battery in the Handset. 11

Battery Charge 11

Programmable Settings. 13

Programming Guidelines. 13

Function Menu Table 14

Display Language 15

Dialing Mode 15

Line Mode 16

Auto Talk. 16

Ringer Volume 17

Ringer Tone 18

LCD Contrast 19

Message Alert 19

Basic Operation

Making Calls 20

Answering Calls 23

Caller ID Service. 24

Using the Caller List 25

Viewing the Caller List. 25

Calling Back from the Caller List 26

Editing the Caller's Phone Number 27

Caller ID Number Auto Edit . . 28

Storing Caller Information in the Phone Book. 29

Erasing Caller Information. . . . 29

Advanced Operation

Phone Book 30

Storing Names and Numbers . . . 30

Dialing from the Phone Book . . 32

Chain Dial 33

Editing an Item in the Phone Book. 34

Erasing an Item in the Phone Book. 34

Copying Items in the Phone Book. 35

Intercom 37

Intercom between Handsets . . 37

Transferring a Call 38

Conference Calls 39

Call Share 39

Voice Mail Service 40

Storing a Voice Mail Access Number 40

Setting Voice Mail (VM) Tone Detection 41

Listening to Voice Mail Messages 42

Special Features. 43

Handset Locator 43

Muting Your Conversation. . . . 43

Call Privacy 43

Temporary Tone Dialing (For Rotary or Pulse Service Users) . 44

For Call Waiting Service Users. 44

Using the PAUSE Button (For PBX Line/Long Distance Calls). 45

FLASH Button 45

Incoming Call Tone 46

Key Tone. 46

Useful Information

Belt Clip 47

Optional Headset 47

Wall Mounting 48

Direct Commands 51

Canceling Registration/ Re-registration 52

Canceling the Handset Registration 52

Re-registering the Handset . . . 53

If the Following Appear on Your Display... 55

Troubleshooting 57

openLCR Service for Caller IQ 61

Turning on or off Caller IQ Feature 61

Downloading Data 62

Important Safety Instructions 65

FCC and Other Information . . . 67

Specifications 70

Index 71

Warranty 73

Important

Throughout these Operating Instructions, **Handset** and **Base Unit** are used to indicate with which unit an operation can be performed.

Handset: Perform with the handset.

Base Unit: Perform with the base unit.

Handset & Base Unit: Perform with the handset and base unit together.

For Best Performance

Battery charge

The handset is powered by a rechargeable Nickel-Metal Hydride (Ni-MH) battery. Charge the battery for **6 hours** before initial use (p. 11).



(KX-TG5202 only)

Base unit location/Noise

Calls are transmitted between the base unit and handset using wireless radio waves. **For maximum distance and noise-free operation**, the recommended base unit location is:


Away from electrical appliances such as a TV, personal computer or another cordless phone.
In a HIGH and CENTRAL location with no obstructions such as walls.
Raise the antennas.

Note:

- If you use the handset near a microwave oven which is being used, noise may be heard from the receiver or the speaker. Move away from the microwave oven and closer to the base unit.
- If you use the handset near another cordless phone's base unit, noise may be heard. Move away from the other cordless phone's base unit and closer to your base unit.

Location of Controls

Base unit



Handset

Location of Controls

Charger unit (KX-TG5202 only)



How to use the soft keys/navigator key

Handset soft keys



Three soft keys are used to select functions displayed directly above each key. Functions displayed above each key will change depending on the state of use.

On this sample display, "**CID**" and "📖" are displayed above the soft keys.

Pressing the right soft key selects the Phone Book "📖".

Pressing the left soft key to review Caller ID information in the Caller List "**CID**".

- When a function name does not appear above a soft key, the soft key has no function.

Throughout these Operating Instructions, the soft keys are indicated by their icons, such as **CID** and 📖.

Handset navigator key

Scrolls up **[▲]** and down **[▼]** the function menu, the Caller List and the phone book.
Increases **[▲]** or decreases **[▼]** the handset ringer and receiver/speaker volumes.

Throughout these Operating Instructions, the handset navigator key is indicated by the arrows **[▼]** or **[▲]**.

Display

Handset



① “**IN USE**” functions as follows.

Off (invisible)	The line is free.
On	The line is being used.
Flashing	A call is on hold.
Flashing rapidly	A call is being received.

② “SP” is shown when you are using the speakerphone.

③ “**VE**” indicates Voice Enhancer mode is on (p. 22).

④ “PRIVACY” indicates Call Privacy mode is on (p. 43). Other extension users cannot join your conversation.

⑤ The battery icon indicates battery strength (p. 11).

⑥ The extension number of your handset is displayed if it has been registered to the base unit (p. 3, 53, 54).

⑦ The display shows the dialed number, call status, programming options, phone book items, Caller ID information, etc.

⑧ The icons on the bottom line indicate the functions of the corresponding soft keys which are located directly below the display (p. 8).
Ex. The soft key below “🕮” (phone book icon) is used when storing or viewing phone book items (p. 30, 32).

⑨ “▟” (extension icon) and extension numbers are displayed (Ex. handset 1=“1”, handset 2=“2”) during an intercom call (p. 37) or a conference call (p. 39).

Installation

Connections

Base unit



- Base unit: USE ONLY WITH Panasonic AC ADAPTOR PQLV1 (Order No. PQLV1Z).
- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- If your unit is connected to a PBX which does not support Caller ID and voice mail services, you cannot access those services.
- This unit will not function during a power failure. We recommend connecting a standard telephone to the same telephone line or to the same telephone jack using the Panasonic KX-J66 T-adaptor.

Charger unit (KX-TG5202 only)



- Charger unit: USE ONLY WITH Panasonic AC ADAPTOR KX-TCA1 (Order No. KX-TCA1-G).
- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)

Installation

Recharge

Recharge the battery when:
— "Recharge battery" is displayed on the handset,
— "▭" flashes, or
— the handset beeps intermittently while it is in use.

- The display will continually indicate "Recharge battery" and/or "▭" will flash when the handset battery is charged for less than 15 minutes and the handset is lifted off the base unit or charger.
- If the battery has been discharged, the handset will display "Charge for 6 HRS" and "▭" when you place the handset on the base unit or charger. The handset will not work unless the battery is charged. Continue charging.

Battery replacement:
If you cleaned the charge contacts and fully charged the battery, but after a few telephone calls, "Recharge battery" is displayed and/or "▭" continues to flash, or "Charge for 6 HRS" and "▭" are displayed, the battery may need to be replaced. Please order a new Panasonic HHR-P104 battery at the telephone number shown on page 2. To replace the battery, see page 11.

A nickel metal hydride battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY for information on how to recycle this battery.

Battery information

After your Panasonic battery is fully charged, you can expect the following performance:

Operation	Operating time
While in use (TALK)	Up to 5 hours
While not in use (Standby)	Up to 11 days
While using the Clarity Booster feature (p. 22)	Up to 3 hours

- A fully charged battery will give you up to 5 hours of continuous talk time, or keep your handset in Standby mode to receive incoming calls for up to 11 days (if no phone calls are made). Battery power is consumed whenever the handset is off of the base unit or charger, even when the handset is not in use. The longer you leave the handset off of the base unit or charger, the time you can actually talk on the handset will be shortened. Actual battery performance depends on a combination of how often the handset is in TALK mode and how often it is in Standby mode.
- **Clean the charge contacts of the handset, the base unit and charger with a soft, dry cloth once a month. Clean more often if the unit is subject to grease, dust or high humidity.** Otherwise the battery may not charge properly.
- If the battery is fully charged, you do not have to place the handset on the base unit or charger until "Recharge battery" is displayed and/or "▭" flashes. This will maximize the battery life.
- If you want to keep the battery fully charged at all times, place the handset on the base unit or charger when the handset is not used. The battery cannot be overcharged.
- When the Clarity Booster feature is turned on automatically or manually, battery operating time may be shortened (p. 22).

Programmable Settings

Programming Guidelines Handset

The unit has several programmable functions which can be selected from the function menu on the display (p. 14).



How to select a function item from the menu

Make sure the handset and base unit are not being used. The handset must be operated near the base unit and while off the base unit or charger.

1 Press **[MENU]**.
- The main menu is displayed (p. 14).



2 Scroll to the desired item by pressing **[▼]** or **[▲]**.

3 Press the soft key (**SELECT**) to select the desired item.

4 If the item has a sub-menu, select the menu item (p. 14). Repeat steps 2 and 3 until the desired item is displayed. If the item has no sub-menu, go to step 5.

5 Select the desired setting by pressing **[▼]** or **[▲]**, then press the soft key (**SAVE**).
- A confirmation tone will be heard and the setting will be saved.

6 Press **[OFF]** to exit programming mode.

- To go back to the previous menu, press the soft key (**BACK**), or press the soft key (**SELECT**) while "---(Go back)----" is displayed. If you press this key in the main menu, the unit will exit programming mode.
- After programming is complete, the display will return to the main menu or the sub-menu depending on which menu the selected item is located. (See the menu table on page 14.)
- You can exit programming mode at any time by pressing **[OFF]**.
- If you do not press any buttons for 60 seconds, the unit will exit programming mode.
- If the unit detects a problem, an error message will be displayed (p. 55–56) and/or error beeps will sound.

Function Menu Table Handset

You can use the following functions to customize your unit. See the corresponding pages for function details.

- After pressing **[MENU]**, you can also program menu items directly by pressing (**[0]** to **[9]**, and **[#]**) instead of using the soft keys (p. 51–52).


Main menu
Sub-menu Ⅰ
Sub-menu Ⅱ
Ringer setting
Ringer volume p. 17
Ringer tone p. 18
Incoming call. p. 46
Voice enhancer p. 22
Caller IQ
* View Info.? p. 64
Get new Info.? p. 63
Turn CIQ off? p. 61
Copy phone book
Copy 1 item p. 35
Copy all items p. 36
Initial setting
Voice Mail
Store VM access# p. 40
VM tone detect p. 41
Message alert p. 19
LCD contrast p. 19
Key tone p. 46
Auto talk p. 16
Caller ID edit p. 28
Set tel line
Set dial mode p. 15
Set flash time p. 45
Set line mode p. 16
Registration
HS registration p. 53
Deregistration p. 52
Change language p. 15
*"Activate CIQ?" is displayed if you have not subscribed to openLCR service. "Turn CIQ on?" is displayed when Caller IQ is turned off (p. 61).

- If you program the Voice Mail (VM) access number, Voice Mail (VM) tone detection, dialing mode, flash time or line mode using one of the handsets, you will not need to program the same item using another handset.

Display Language Handset

You can select either “English” or “Spanish” as the display language. The factory preset is “English”.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 Scroll to “Change language” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



4 To change from English to Spanish, press the soft key (**ESPAÑOL**).
To change from Spanish to English, press the soft key (**ENGLISH**).

- The display changes to the selected language.
- You can also select the display language by pressing **[▼]** or **[▲]**.

5 When Spanish is selected, press the soft key (**GUARDAR**), then press **[OFF]**.
When English is selected, press the soft key (**SAVE**), then press **[OFF]**.

- If you select a language you cannot read, change the display language again using direct commands (p. 51).

Dialing Mode Handset

If you have touch tone service, set the dialing mode to “Tone”. For rotary or pulse service, set to “Pulse”. The factory preset is “Tone”.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



3 Scroll to “Set tel line” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



4 Press the soft key (**SELECT**) at “Set dial mode”.



5 Select “Pulse” or “Tone” by pressing **[▼]** or **[▲]**.



6 Press the soft key (**SAVE**), then press **[OFF]**.

Line Mode Handset

The line mode is preset to “B” and generally should not be adjusted. If “ IN USE ” is not displayed on the handset properly, the line mode selection is incorrect. Set line mode to “A”.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).

3 Scroll to “Set tel line” by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).



4 Scroll to “Set line mode” by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).



5 Select “A” or “B” by pressing **[▼]** or **[▲]**.



6 Press the soft key (SAVE), then press **[OFF]**.

Auto Talk Handset

The Auto Talk feature allows you to answer calls by simply lifting the handset off the base unit or charger (for KX-TG5202 or accessory handset users, p. 3). You do not need to press **[ ]** or **[ ]**. The factory preset is OFF.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).



3 Scroll to “Auto talk” by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).

4 Select “On” or “Off” by pressing **[▼]** or **[▲]**.



5 Press the soft key (SAVE), then press **[OFF]**.

- In order to view Caller ID information after you lift the handset to answer a call, leave the Auto Talk feature turned off.

Ringer Volume Handset

You can set the handset ringer volume to high, medium, low, or off. The factory preset is HIGH. If set to off, the handset will ring at the low level for intercom calls, and will not ring for outside calls.

1 Press **[MENU]**.

2 Press the soft key (**SELECT**) at "`Ringer setting`".

3 Press the soft key (**SELECT**) at "`Ringer volume`".

4 Select the desired volume by pressing **[▼]** or **[▲]**.

- The volume will change and ring.
- The number of steps indicates the volume level.
- **To turn the ringer off**, press **[▼]** repeatedly until "`Off ?`" is displayed.

Ex. High

Ex. Off



5 Press the soft key (**SAVE**).

- If the handset ringer is turned off, the handset displays "`Ringer off`" while not in use. When there are new messages in your voice mailbox (p. 42), "`Ringer off`" is not displayed.
- You can also adjust the ringer volume while an outside call is ringing. Press **[▼]** or **[▲]** while the handset is ringing.

Temporary ringer off

While the handset is ringing for an outside call, you can turn the ringer off temporarily by pressing **[OFF]**. The handset will ring again as normal the next time a call is received.

Ringer Tone Handset

You can set the handset ringer to use one of 7 ringer patterns for outside calls. “Tone 1” to “Tone 3” are bell ringer patterns. “Melody 1” to “Melody 4” are preset melody patterns. The factory preset is “Tone 1”.

- You cannot change the ringer tone for intercom calls.
- If you subscribe to a Distinctive Ring Service (such as IDENTA-RING) from your telephone company with 2 or 3 consecutive rings, select a bell ringer pattern (Tone 1 to 3). If you select a melody pattern, you will not be able to distinguish lines by their ringers.
- If you select one of the melody ringer patterns, the ringer will continue to sound for several seconds if:
  — the caller hangs up before you answer the call, or
  — another person answers the call using another phone connected on the same line.

1 Press **[MENU]**.

2 Press the soft key (**SELECT**) at “`Ringer setting`”.

3 Scroll to “`Ringer tone`” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

4 Select the desired ringer tone by pressing **[▼]** or **[▲]**.

- The handset will ring and the ringer tone will change. If the ringer volume has been turned off, the handset will not ring (p. 17).
- You can also select the ringer tone by pressing **[1]** to **[7]**.



5 Press the soft key (**SAVE**), then press **[OFF]**.

LCD Contrast Handset

There are 6 levels of LCD contrast. The factory preset is “level 3”.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



3 Scroll to “LCD contrast” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

4 Select the desired contrast by pressing **[▼]** or **[▲]**.

- The contrast will change.
- The number of steps indicates the contrast level.

Ex. Level 3

5 Press the soft key (**SAVE**), then press **[OFF]**.

Message Alert Handset

You can select whether or not the Ringer/Message Alert indicator on the handset will flash slowly when new messages in your voice mailbox have been recorded (p. 42). The factory preset is OFF.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



3 Scroll to “Message alert” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



4 Select “On” or “Off” by pressing **[▼]** or **[▲]**.



5 Press the soft key (**SAVE**), then press **[OFF]**.

- The Ringer/Message Alert indicator will not flash for new messages while the handset is in use.
- The Ringer/Message Alert indicator acts as a ringer indicator and as a message alert indicator. This indicator will flash rapidly when a call is received whether this feature is on or off.
- Battery operating time may be shortened when using this feature (p. 12).

Making Calls

System capabilities (Operating more than one handset, p. 3)
Up to 2 handsets can operate at a time. The maximum operating number may decrease depending on the state of use.

1 Press **[ ]**.
- "Talk" is displayed.

2 Dial a phone number.
- The dialed number is displayed.
- After a few seconds, the display will show the length of the call.

3 To hang up, press **[OFF]** or place the handset on the base unit or charger (for KX-TG5202 or accessory handset users, p. 3).

To have a hands-free phone conversation

1 Press **[ ]**.
- "SP-phone" is displayed.

2 Dial a phone number.
- The dialed number is displayed.
- After a few seconds, the display will show the length of the call.

3 When the other party answers, talk into the microphone.

4 To hang up, press **[OFF]** or place the handset on the base unit or charger.



Hands-free Digital Duplex Speakerphone

For best performance, please note the following:
- Talk alternately with the other party in a quiet room.
- If you or the other party has difficulty hearing, press **[▼]** to decrease the speaker volume.
- While talking using **[ ]**, you can switch to a hands-free phone conversation by pressing **[ ]**. To switch back to the receiver, press **[ ]**.

dial ed is displ ayed.

down through the list by pressing [REDIAL/OFF].

to transfer the call to another handset, see page 38.



Voice Enhancer Technology

Panasonic's Voice Enhancer Technology clarifies the voice of the person you are talking to, reproducing a more natural-sounding voice that is easier to hear and understand. Voice Enhancer Technology can be turned on or off. The factory preset is OFF.

- Depending on the condition and quality of your telephone line, this feature may emphasize existing line noise. If it becomes difficult to hear, turn this feature off.

To turn this feature on, press the soft key (**(VE)**) during a conversation.



- "**VE**" is displayed.
- **To turn this feature off**, press the soft key (**(VE)**) again. "**VE**" disappears from the display.
- After hanging up a call, the on/off setting will be retained.

When the handset is not in use, you can also turn this feature on or off by programming as follows:

1. Press **[MENU]**.
2. Scroll to "Voice enhancer" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).
3. Select "On" or "Off" by pressing **[▼]** or **[▲]**.
4. Press the soft key (**SAVE**), then press **[OFF]**.

Clarity Booster

This feature can improve sound clarity when the handset is used in an area where there may be interference. During an outside call, this feature will be turned on automatically when necessary. This feature will turn off when you hang up, put a call on hold, or make a conference call. It will not turn off automatically during a call. You can also turn this feature on or off manually.

1. Press **[MENU]** during an outside call.
2. Press **[2]** to select "2=Booster on" or "2=Booster off".



   - You can also select "2=Booster on" or "2=Booster off" by pressing **[▼]** then pressing the soft key (**SELECT**).

- While this feature is turned on, "Booster on" will flash during a conversation.
- If this feature is turned off manually during a call, it will not be turned on automatically during the same call.
- When this feature is turned on automatically or manually, battery operating time may be shortened (p. 12).
- The maximum number of extensions which can be used at a time may decrease when using this feature.

Backlit LCD display/Lighted handset keypad

The handset display and dialing buttons will light for a few seconds after pressing a button or lifting the handset off the base unit or charger (for KX-TG5202 or accessory handset users, p. 3).

Answering Calls

When a call is received, the unit rings, "Incoming call" is displayed, and the Ringer/Message Alert indicator on the handset and the IN USE indicator on the base unit flash rapidly.

1 Press **[ ]** or **[ ]**.
- You can also answer a call by pressing any button except **[▼]**, **[▲]** or **[OFF]**.

2 To hang up, press **[OFF]** or place the handset on the base unit or charger.



Auto Talk
If the Auto Talk feature is turned on (p. 16), you can answer a call by simply lifting the handset off the base unit or charger (for KX-TG5202 or accessory handset users, p. 3).

Temporary ringer off
While the handset is ringing for an outside call, you can turn the ringer off temporarily by pressing **[OFF]**. The handset will ring again as normal the next time a call is received.

- **To transfer the call to another extension, see page 38.**
- If the ringer volume is turned off, the unit will not ring (p. 17).

Caller ID Service

This unit is compatible with Caller ID services offered by your telephone company. If you subscribe to Caller ID, caller names and phone numbers will be displayed and recorded in the Caller List.

How Caller ID information is displayed

When a call comes in, the unit will ring and Caller ID information will be received. The handset display will show the caller's information.*

- After you answer the call, the display will show the length of the call.

Example

```
ROBINSON,TINA
1-555-222-3333
```

*Personalized Name Display

If you receive a call from one of the same phone numbers stored in the phone book, the handset will show the caller's name stored in the phone book instead of incoming caller's name.

- If the unit does not receive Caller ID information, one of the following will be displayed:

Display	Meaning
`Out of area`	The caller dialed from an area which does not provide Caller ID service.
`Private caller`	The caller requested not to send his/her information.
`Long distance`	The caller made a long distance call.

- Depending on radio communications with the base unit, the handset may not display Caller ID information immediately after the first ring.
- If your unit is connected to a PBX which does not support Caller ID, you cannot access Caller ID service.
- Name display service may not be available in some areas. For further information, please contact your telephone company.
- If you subscribe to both Caller ID and Call Waiting with Caller ID service (CWID), when a second call is received while talking, a call waiting tone will be heard and the second caller's information will be displayed (p. 44).
  Contact your telephone company for details about availability in your area, and to verify that CWID service is activated on your telephone line.

Using the Caller List

The unit can record information up to 50 different callers and store this information in the Caller List. Caller information is sorted by the most recent call to the oldest. When the 51st call is received, the information from the 1st call is deleted.

The unit will also tell you how many calls you missed while you were out or unavailable to answer the phone.



② Stands for Caller ID

① The display will show the number of calls you missed.

② Press the soft key (**CID**), **[▼]**, or **[▲]** to review other calls logged in the Caller List.

- If there are no items in the Caller List, "**CID**" will not be displayed.
- After viewing the missed call entries, "missed calls" will disappear from the display.

Viewing the Caller List Handset

1 Press the soft key (**CID**), **[▼]**, or **[▲]** to enter the Caller List.

Ex. 10 calls missed.



2 To search from the most recent call, press **[▼]**. To search from the oldest call, press **[▲]**.

- The caller's name, number and the time and date of the call are displayed.

Example



3 Press **[OFF]** to exit the list.

- If there is no name information for a caller and you do not store the name and phone number in the phone book, the display will only show the phone number.
- Each handset has its own Caller List. If you viewed the Caller List or answered a call on one handset, the same information in the other handsets will be displayed as "missed".
- If you do not press any buttons for 60 seconds, the unit will exit the Caller List.

Using the Caller List

What "√" means

"√" indicates you have already viewed this calling information or answered the call. If the same caller calls again, the call entry with the "√" will be replaced with the new call entry.



If a caller calls more than once

The number of times the same caller called is displayed ("×2" to "×9"). The date and time of the most recent call will be recorded. After viewing a caller's information, "×2" to "×9" will be replaced with "√".

Ex. Called 3 times.



Calling Back from the Caller List Handset

1 Press the soft key (**CID**), **[▼]**, or **[▲]** to enter the Caller List.

2 Scroll to the desired caller by pressing **[▼]** or **[▲]**.

3 Press **[ ]** or **[ ]**.

- The phone number is dialed.

- In some cases, you may have to edit the number before dialing (p. 27). (Ex. You may have to delete "1" and the area code.)
- If a phone number is not displayed in the caller information, you cannot call that caller back from the Caller List.

Editing the Caller's Phone Number Handset

You can edit a phone number in the Caller List by removing its area code and/or the long distance code "1".
Once you call back an edited number, this unit can automatically edit incoming phone numbers from the same area code in the Caller List and each time you receive a call (**Caller ID Number Auto Edit,** p. 28).

1 Press the soft key (**CID**), **[▼]**, or **[▲]** to enter the Caller List.

2 Scroll to the desired caller by pressing **[▼]** or **[▲]**.

3 Press the soft key (**EDIT**) repeatedly until the number is shown in the desired format.

- Each time you press the soft key (**EDIT**), the number is rearranged into one of 3 patterns.

ⓐ Phone no.
ⓑ Area code – Phone no.
ⓒ 1– Area code – Phone no.

- The order in which patterns ⓐ–ⓒ are displayed depends on how the telephone number is displayed in step 2.



4 To call the edited number, press **[ ]** or **[ ]**.

- If Caller ID Number Auto Edit feature is turned on (factory preset is on), phone numbers with the same area code as the number you edited will now be edited in the Caller List and each time you receive a call.
- You can press **[OFF]** immediately after pressing **[ ]** or **[ ]** if you wish to activate the Auto Edit feature without actually dialing the number you just edited.

To save the edited number into the phone book, press the soft key (**SAVE**).

- If there is no name information, see "Storing Caller Information in the Phone Book" on page 29, from step 3.
- Even if the Auto Edit feature is turned on, this feature will not be activated by saving the edited number in the phone book.

- If you receive a call from a 7-digit phone number stored in the phone book, "**EDIT**" will not be displayed when the call's Caller ID information is displayed.

Caller ID Number Auto Edit Handset

Once you call back an edited number (p. 27), this unit can automatically edit incoming phone numbers from the same area code in the Caller List and each time you receive a call. For example, it can ignore the area code of calls originating from your area code, so that you can call these numbers from the Caller List without dialing the area code.

To activate this feature, you must edit a caller's phone number in the Caller List (p. 27) by selecting pattern ⓐ, ⓑ, or ⓒ, then make a call to that number. Calls from numbers in that area code will be edited automatically. The unit can remember up to 4 area codes to be edited according to patterns ⓐ and ⓑ.

When more than 5 area codes are edited, older area codes are reset to pattern ⓒ. Phone numbers from the 4 most recently edited area codes will be automatically edited.

You can turn this feature on or off using the handset. The factory preset is ON.

To turn on or off Caller ID Number Auto Edit feature

1 Press **[MENU]**.

2 Scroll to "Initial setting" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 Scroll to "Caller ID edit" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

4 Select "Off" or "On" by pressing **[▼]** or **[▲]**.



5 Press the soft key (**SAVE**), then press **[OFF]**.

- If you fail to reach your destination when making a call, the phone number you dialed might have an incorrect pattern. Edit the phone number with another pattern (p. 27).
- When this feature is turned off, the unit will still be able to display Caller ID, but incoming Caller ID numbers will not be automatically edited.
- If you move to another area you may need to turn this feature off to erase the previously edited area codes. To use this feature again, turn it on and reprogram the area codes you want to be edited once again.

Storing Caller Information in the Phone Book Handset

Caller names and phone numbers that are in the Caller List can be stored in the phone book.

1 Press the soft key (**CID**), **[▼]**, or **[▲]** to enter the Caller List.

2 Scroll to the desired caller by pressing **[▼]** or **[▲]**.
- If the number requires editing, see page 27.

3 Press the soft key (**SAVE**).
- If there is no name information for the caller, "`Enter name`" will be displayed.
  - — You can enter a name by performing the following steps:
    (1) enter the name (p. 31),
    (2) press **[▼]**, and
    (3) press the soft key (**SAVE**).
  - — If a name is not required, press **[▼]**, then press the soft key (**SAVE**).
- To continue storing other items, repeat from step 2.
- To exit programming mode, press **[OFF]**.

- You cannot store Caller List items in the phone book if a phone number is not displayed.

Erasing Caller Information Handset

To erase a specific caller

1 Press the soft key (**CID**), **[▼]**, or **[▲]** to enter the Caller List.

2 Scroll to the desired caller by pressing **[▼]** or **[▲]**.

3 Press the soft key (**ERASE**).
- "`Erased`" is displayed.
- To erase other items, repeat from step 2.
- To exit the Caller List, press **[OFF]**.

To erase all entries

1 Press the soft key (**CID**), **[▼]**, or **[▲]** to enter the Caller List.
- Before erasing all entries, make sure that "`0 missed call`" is displayed.

2 Press the soft key (**ERASE**).
- "`All erase?`" is displayed.
- To cancel erasing, press the soft key (**NO**).

3 Press the soft key (**YES**).
- "`All erased`" is displayed and all entries in your Caller List are erased.

Phone Book

The handset can store up to 50 names and phone numbers in its phone book. You can make a call by selecting a name or number from the phone book, and copy phone book items from one handset to another (p. 35, 36).

Storing Names and Numbers Handset

1 Press the soft key (📖).
- The display will show the number of stored items.



2 Press the soft key (**ADD**).

3 Enter a name of up to 16 characters with the dialing buttons (**[0]** to **[9]**) (p. 31), then press **[▼]**.
- To move the cursor, press the soft key (◄) or (►).
- If a name is not required, press **[▼]** then go to step 4.



4 Enter a phone number of up to 32 digits.
- To delete a digit, press the soft key (**CLEAR**). To erase all of the digits, press and hold the soft key (**CLEAR**).



5 Press **[▼]**.
- If you want to change the name, press the soft key (**EDIT**). The display returns to step 3. Change the name.
- If you want to change the number, press **[▲]**. The display returns to step 4. Change the number.

6 Press the soft key (**SAVE**).
- To continue storing other items, repeat from step 2.

7 Press **[OFF]**.

- If a pause is required when dialing, press the soft key (**PAUSE**) in step 4. A pause is stored in a phone number as one digit (p. 45).
- To store numbers for calling card access (see “Chain Dial” on page 33), we recommend you add pauses after each item. Storing pauses with numbers will prevent misdialing (p. 45). The delay time necessary will depend on your telephone company.

Selecting characters to enter names

Enter names using the dialing buttons. Press each button until the desired character is displayed.

• Pressing each button selects a character in the order shown below.

Keys	Characters	Keys	Characters
[1]	# & ' ( ) * , – . / 1	[6]	m n o M N O 6
[2]	a b c A B C 2	[7]	p q r s P Q R S 7
[3]	d e f D E F 3	[8]	t u v T U V 8
[4]	g h i G H I 4	[9]	w x y z W X Y Z 9
[5]	j k l J K L 5	[0]	0 Space
◄	Moves the cursor to the left.		
►	Moves the cursor to the right. (To enter another character using the same number key, move the cursor to the next space.)		

For example, to enter "Tom":

1. Press **[8]** four times.
2. Press **[6]** three times, then press the soft key (►) to move the cursor.
3. Press **[6]** once.



If you make a mistake while entering a name or number

1. Press the soft key (◄) or (►) to move the cursor to the incorrect character.
2. Press the soft key (CLEAR) to delete the character.
   • Each time you press the soft key (CLEAR), a character is erased.
   • To erase all characters, press and hold the soft key (CLEAR).
3. Enter the correct character.

Dialing from the Phone Book Handset

1 Press the soft key (📖).
- The display shows the number of stored items.
- You can press the soft key (**SEARCH**) to view the first item.



2 Scroll to the desired item. To scroll down, press **[▼]**. To scroll up, press **[▲]**.

Phone book items are sorted in the following order:	
1	Alphabet letters (Alphabetical)
2	Space & ’ ( ) , – . /
3	Numbers 0 to 9
4	# ✳
5	Telephone numbers (If no name is stored)



3 Press **[↷]**, **[🔊]**, or the soft key (**CALL**).
- The phone number is dialed.

- If “No items stored” is displayed in step 1, the phone book is empty.
- To exit the phone book, press **[OFF]**.

To search for a name by initial

1. Press the soft key (📖).
2. Press the dialing button for the first letter of the desired name until any name with the same initial is displayed (see the Index table below).

   Ex. To find “Frank”, press **[3]** repeatedly until the first item under “F” is displayed.
   - If there are no items beginning with the character you selected, the first item in the next alphabetical index will be displayed.
3. Press **[▼]** repeatedly until the desired name is displayed.

Index table

Keys	Index	Keys	Index
[1]	Symbols, 1	**[6]**	M, N, O, 6
[2]	A, B, C, 2	**[7]**	P, Q, R, S, 7
[3]	D, E, F, 3	**[8]**	T, U, V, 8
[4]	G, H, I, 4	**[9]**	W, X, Y, Z, 9
[5]	J, K, L, 5	**[0]**	0, Space

Chain Dial Handset

You can dial a combination of phone book or manual key pad entries while making a call. This feature can be used, for example, to first automatically dial a calling card access number that you have stored in the phone book, then manually or automatically dial your PIN and then automatically dial the destination from the phone book.

Ex. Using a long distance calling card

- To prevent misdialing, we recommend you add pauses where needed when storing numbers. For example, add pauses after a calling card access number and your PIN when storing in the phone book (p. 30).

1. Search and dial from the phone book: 1-800-012-3456 (Calling card access number)
   - The voice guidance will be announced.
2. Search and dial from the phone book: 1234 (Calling card PIN)
3. Search and dial from the phone book: 1-555-012-3456 (Destination Number)

1 **While you are on a call;**
Press **[MENU]**.



2 Press the soft key (**SELECT**) at "1=Phone book", or press **[1]**.



3 Search for the desired item by pressing **[▼]** or **[▲]**.
- To search for an item by initial, see page 32.

4 Press the soft key (**CALL**).
- The phone number is dialed.
- If required, repeat steps 1 to 4 for any remaining numbers.

- If you have rotary or pulse service, you need to press **[✳]** before pressing **[MENU]** in step 1 to change the dialing mode temporarily to tone.

Editing an Item in the Phone Book Handset

1 Press the soft key (📖).

2 Scroll to the desired item by pressing **[▼]** or **[▲]**.
- To search for the item by initial, see page 32.

3 Press the soft key (**EDIT**).



4 Edit the name (p. 31), then press **[▼]**.
- If you do not need to change the name, press **[▼]** then go to step 5.
- To move the cursor, press the soft key (**◄**) or (**►**).



5 Edit the phone number, then press **[▼]**.
- If you do not need to change the number, press **[▼]** then go to step 6.
- To delete a digit, press the soft key (**CLEAR**). To delete all of the digits, press and hold the soft key (**CLEAR**).



6 Press the soft key (**SAVE**).
- To continue editing other items, repeat from step 2.

7 Press **[OFF]**.

Erasing an Item in the Phone Book Handset

1 Press the soft key (📖).

2 Scroll to the desired item by pressing **[▼]** or **[▲]**.
- To search for the item by initial, see page 32.

3 Press the soft key (**ERASE**).
- To cancel erasing, press the soft key (**NO**).

4 Press the soft key (**YES**).
- To erase other items, repeat from step 2.

5 Press **[OFF]**.

Copying Items in the Phone Book Handset
(When the System Has Two or More Handsets)

You can copy one or all phone book items between two handsets. The destination handset will save the items in its phone book.

- If an outside call is received during the phone book copy, copying will stop. You will need to re-send the item(s) later.
- After the copy has started, do not place your handset on the base unit or charger (for KX-TG5202 or accessory handset users, p. 3) until copying finishes, otherwise copying will stop.

To copy one phone book item to another handset

Make sure the destination handset is not in use.

1 Press **[MENU]**.

2 Scroll to "Copy phone book" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 Press the soft key (**SELECT**) at "Copy 1 item".



4 Select the destination extension number (1 to 4) by pressing **[▼]** or **[▲]**.

- You can also select the extension number by pressing **[1]** to **[4]**.



5 Press the soft key (**NEXT**).



6 Scroll to the desired phone book item by pressing **[▼]** or **[▲]**.

- To search for the item by initial, see page 32.

7 Press the soft key (**SEND**).

- To continue copying other items, repeat from step 6.

8 Press **[OFF]**.

To copy all of the items in your phone book to another handset

Make sure the destination handset is not in use.

1 Press **[MENU]**.

2 Scroll to "Copy phone book" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 Scroll to "Copy all items" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

4 Select the destination extension number (1 to 4) by pressing **[▼]** or **[▲]**.

- You can also select the extension number by pressing **[1]** to **[4]**.



5 Press the soft key (**SEND**).

- When all items have been copied, "Complete" is displayed.
- The destination handset displays "Phone book Receiving" then "Phone book Received".
- To continue copying items to another extension, repeat from step 3.

Ex. Copying 1st item out of 10 items



6 Press **[OFF]**.

- You can exit phone book copying mode by pressing **[OFF]**.

Intercom

Intercom between Handsets Handset
(When the System Has Two or More Handsets)

Intercom calls can be made between two handsets (when the system has two or more handsets, p. 3). Page the desired unit(s) by entering the extension number, shown in the top right of each handset's display.

Ex. From the Handset 1 to the Handset 2

1 *Handset 1:*
Press **[HOLD/INTERCOM]**.



2 *Handset 1:*
To page another handset, press its extension number (**[1]** to **[4]**).
- The paged handset will ring for 1 minute and the Ringer/Message Alert indicator flashes rapidly.
- To stop paging, press **[OFF]**.

Ex. Calling Handset 2

3 *Handset 2:*
Press **[ ]**, **[ ]** or **[HOLD/INTERCOM]** to answer the page.
- Any button except **[▼]**, **[▲]** or **[OFF]** can be pressed to answer the page.

Ex. Handset 1 calling

4 *Handset 1:*
When the paged party answers, start talking.

5 *Handset 1 or Handset 2:*
To disconnect the intercom, press **[OFF]**.

- If the Auto Talk feature is turned on (p. 16), you can also answer a page by simply lifting the handset off the base unit or charger (for KX-TG5202 or accessory handset users, p. 3).

During an intercom call:
- You can switch to the speaker by pressing **[ ]**. To switch back to the receiver, press **[ ]**.
- If you have difficulty hearing while using the speakerphone on the handset, decrease the speaker volume by pressing **[▼]**.
- If an incoming call is being received, you will hear two tones (incoming call tone, p. 46) and the IN USE indicator on the base unit will flash rapidly. To answer the call, press **[OFF]**, then press **[ ]** or **[ ]**.

- When the ringer volume is turned off (p. 17), the handset will ring at the low level for intercom calls.
- You cannot change the ringer tone for intercom calls.

Transferring a Call

You can transfer an outside call to another handset.

From a Handset to another Handset

(when the system has two or more handsets)

Ex. From the Handset 1 to the Handset 2

1 *Handset 1:*
(1) During a call, press **[HOLD/INTERCOM]**.
- The call is put on hold.

(2) To page another handset, press its extension number (**[1]** to **[4]**).
(Ex. Press **[2]** to page the handset 2.)
- If the paged party does not answer, press **[ ]** or **[ ]** to return to the outside call.

2 *Handset 2:*
Press **[ ]**, **[ ]** or **[HOLD/INTERCOM]** to answer the page.
- Any button except **[▼]**, **[▲]** or **[OFF]** can be pressed to answer the page.

3 *Handset 1:*
You can announce the transfer.
To complete the transfer, press **[OFF]**.

- If the Auto Talk feature is turned on (p. 16), the paged handset user can also answer a page by simply lifting the handset off the base unit or charger (for KX-TG5202 or accessory handset users, p. 3).
- Any user can answer a transferred call by pressing **[ ]** or **[ ]**.
- If you call an extension from the handset in step 1, and the extension is in use, the display will show "Busy" then "Hold". Press **[ ]** or **[ ]** to return to the outside call. To transfer the call to another extension, repeat from step 1.

Quick call transfer Handset

You can transfer a call without waiting for the paged party to answer.

1. During a call, press **[HOLD/INTERCOM]**.
2. Press the extension number (**[1]** to **[4]**).
3. Press **[OFF]** to hang up.

- The call will be transferred directly.
- The paged party can answer the transferred call by pressing **[ ]** or **[ ]**.
- After the paged party answers, the transfer is complete.
- If the paged party does not answer, press **[ ]** or **[ ]** to return to the outside call.
- If the paged party does not answer within 60 seconds after you hang up, your phone will ring and the call will be returned to your phone. You may speak to the caller again by pressing **[ ]** or **[ ]**.
  If you do not answer the call within 4 minutes, the call will be disconnected.

Conference Calls

While you are talking with an outside caller, a handset user can join the conversation and establish a conference call.

Handset

1 During a call, press **[HOLD/INTERCOM]**.
- The call is put on hold.

2 To page another handset, press the extension number (**[1]** to **[4]**).

3 When the paged party answers, press the soft key (**CONF**) on your unit to make a conference call.

- To leave the conference, press **[OFF]**. The two other parties can continue the conversation.
- During a conference, the outside call can be placed on hold by pressing **[HOLD/INTERCOM]**. Internal communications between extensions are not suspended. Only the person who placed the call on hold can resume the full conference by pressing the soft key (**CONF**).
- A maximum of three parties including the outside party can take part in a conference call.

Call Share Handset

This feature allows the handset to join an existing outside call.

- To prevent other users from joining your conversation, turn the Call Privacy feature on (p. 43).

To join a conversation (Call Share)

Press **[ ]** or **[ ]**.

- "Conference" is displayed.
- A maximum of three parties including the outside party can join a conversation.

Voice Mail Service

Voice mail is an automatic answering service offered by your telephone company. If you subscribe to this service, your telephone company's voice mail system can answer calls for you when you are unavailable to answer the phone or when your line is busy. Callers can leave messages that are saved in virtual voice mailboxes, which are maintained for you at the phone company, allowing you to listen to your messages whenever you like.
The unit will let you know that someone has left voice mail for you (p. 42).
Once you have stored your voice mail access number, you can access your voice mailbox simply by pressing the soft key (**V M**), then pressing **[📞]** or **[🔊]** on the handset.

Storing a Voice Mail Access Number Handset

1 Press **[MENU]**.

2 Scroll to "`Initial setting`" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 Press the soft key (**SELECT**) at "`Voice Mail`".

4 Press the soft key (**SELECT**) at "`Store VM access#`".

5 Enter your access number, up to 32 digits.

- If a pause is required for dialing, press the soft key (**PAUSE**).*
- Each time you press the soft key (**CLEAR**), a digit is erased. To erase all of the digits, press and hold the soft key (**CLEAR**).

Example



6 Press the soft key (**SAVE**), then press **[OFF]**.

- "**V M**" is displayed.

*To prevent misdialing, you may add pauses between your voice mail access number and your mailbox password in step 5.

Ex. 1-222-333-4444 PPPP 8888

Your voice mail access number — Pauses — Your mailbox password

Pressing the soft key (**PAUSE**) once creates a 3.5 second delay and counts as one digit. The delay time necessary between entering your access number and entering your mailbox password will depend on your telephone company.

To erase a stored voice mail access number

Repeat steps 1 to 4 on page 40, then press and hold the soft key (CLEAR) until all of the digits are erased. Press the soft key (SAVE), then press **[OFF]**.

Setting Voice Mail (VM) Tone Detection Handset

Your telephone company sends special signals (Voice mail tones) to the unit. Press **[ ]** or **[ ]** to listen to the dial tone. If you hear a series of dial tones followed by a continuous dial tone, this indicates that a new message was recorded. Voice Mail detection is preset at the factory to ON. Minutes after you hang up or after the phone stops ringing, your unit will seize the phone line and check if a message has been recorded. If a new message was recorded at your telephone company, "Voice Mail" will be displayed on the handset, the Ringer/Message Alert indicator on the handset will flash slowly if Message Alert is turned on (p. 19), and the VM indicator will flash on the base unit.

Turn off this programming when:

— you do not subscribe to a voice mail service,
— your telephone company does not send a series of tones, followed by a continuous tone to indicate you have new voice mail, or
— your phone is connected to a business or office telephone system (PBX).

See below to turn this setting off.

If you are not sure which setting is required, consult your local telephone company or contact the Panasonic Customer Call Center.

1 Press **[MENU]**.

2 Scroll to "Initial setting" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).



3 Press the soft key (SELECT) at "Voice Mail".

4 Scroll to "VM tone detect" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).

5 Select "Off" or "On" by pressing **[▼]** or **[▲]**.



6 Press the soft key (SAVE), then press **[OFF]**.

Listening to Voice Mail Messages Handset

The unit will let you know that someone has left new voice mail for you:
(a) the VM indicator will flash on the base unit,
(b) "Voice Mail" will be displayed on the handset,
(c) "VM" will flash on the handset, and
(d) the Ringer/Message Alert indicator on the handset will flash slowly if Message Alert is turned on (p. 19) and the handset is not in use.

To listen to your voice mail message(s)

1 Press the soft key (VM), then press **[📞]** or **[🔊]**.

- "Dial VM access#" is displayed and the number is dialed (p. 40).
- If the handset beeps 3 times and "Store VM access#" is displayed, a voice mail access number is not stored. To store the number, see page 40.

2 Follow the pre-recorded instructions.

3 When finished, press **[OFF]**.

- After listening to your message(s), "VM" stops flashing but remains on the handset display.
- If the handset and base unit still indicate you have new messages even after you have listened to them, turn the voice mail indicators off by pressing and holding **[OFF]** until the handset beeps. "Voice Mail" will disappear and "VM" stops flashing but remains on the handset, and the Ringer/Message Alert indicator on the handset and the VM indicator on the base unit will go out.
- If your voice mail service uses a voice mail tone and the recorded message is over 3 minutes long, the handset and base unit may not indicate you have new messages.
- If your voice mail service uses a voice mail tone, the tone will be heard from any parallel connected phone. If you use another phone to retrieve messages, you have to dial your access number manually.

Special Features

Handset Locator Base Unit

You can locate the handset or page the handset user with beep tones at once from the base unit.

1 To page all handsets, press **LOCATOR [ALL]**.
To page a specified handset, press its extension number **LOCATOR [1]**, **[2]**, **[3]** or **[4]**.

- The IN USE indicator on the base unit and the Ringer/Message Alert indicator on the handset flash rapidly.
- The paged handset(s) will ring for 1 minute and display "`Call from Base`".

2 To stop paging,
Base unit:
Press **LOCATOR [1]**, **[2]**, **[3]**, **[4]** or **[ALL]**.
OR
Handset:
Press **[OFF]**.

- You can also stop paging by pressing any button except **[▼]** or **[▲]**.

Muting Your Conversation Handset

During a call, you can mute your phone so the other party cannot listen to you. When muting your conversation, you can hear the other party.

Press the soft key (MUTE).

- "`Mute`" will be displayed for a few seconds and "MUTE" will flash.
- **To release the mute**, press the soft key (MUTE) again.
- If you press **[📞]** or **[🔊]** to switch between the receiver and speaker, the mute will be released.

Call Privacy Handset

Call Privacy allows you to prevent other users from joining your conversation with an outside caller. To allow other users to join your conversation, leave this feature off. This feature is only available for the handset.

To turn on the Call Privacy feature:
Press the soft key (PRIVACY) during a conversation.

- "PRIVACY" will be displayed.
- To turn this feature off, press the soft key (PRIVACY) again during a conversation.
- While the Call Privacy feature is turned on, other users cannot join the conversation.
- Call Privacy will turn off after you hang up the call.

Temporary Tone Dialing

(For Rotary or Pulse Service Users) Handset

Press **[✳]** (TONE) before entering access numbers which require tone dialing.

- The dialing mode changes to tone. You can enter numbers to access an answering service, electronic banking service, etc. When you hang up, the dialing mode will return to pulse.

For Call Waiting Service Users Handset

Press **[FLASH/CALL WAIT]** if you hear a call waiting tone during a conversation.

- The first call is put on hold and you can answer the second call.
- To return to the first caller, press **[FLASH/CALL WAIT]** again.
- Call Waiting service cannot be used when the first call is put on hold.
- If this function does not operate properly, consult your telephone company for details.

Call Waiting Caller ID display Handset

If you subscribe to both Caller ID and Call Waiting with Caller ID services (CWID), when a second call is received while talking, the second caller's information will be displayed. After you hear a call waiting tone while talking, the display shows the caller's name with the phone number and "Waiting".

- Contact your telephone company for details about availability in your area, and to verify that CWID service is activated on your telephone line.
- The caller's information will only be shown on the display of the handset which is on the outside call.

Using the PAUSE Button (For PBX Line/Long Distance Calls)

Handset

We recommend you press the soft key (PAUSE) if a pause is required for dialing with a PBX or to make a long distance call.

- "PAUSE" is displayed on the handset only when dialing before pressing **[ ]** or **[ ]** (p. 21), or storing numbers in the phone book (p. 30).

Ex. Line access number **[9]** (PBX)

[9] ➡ Soft key (PAUSE) ➡ Phone number

- Pressing the soft key (PAUSE) once creates a 3.5 second pause. This prevents misdialing when you dial after confirming the entered number (p. 21) or dial a stored number (p. 32, 33).
- Pressing the soft key (PAUSE) more than once increases the length of the pause between numbers.

FLASH Button Handset

Pressing **[FLASH/CALL WAIT]** allows you to use special features of your host PBX such as transferring an extension call, or accessing optional telephone services such as call waiting.

- Pressing **[FLASH/CALL WAIT]** cancels the mute or the Temporary Tone Dialing mode (p. 43, 44).

Selecting the flash time

The flash time depends on your telephone exchange or host PBX.
You can select the following flash times: "700, 600, 400, 300, 250, 110, 100 or 90 ms (milliseconds)". The factory preset is "700 ms".

- If PBX functions do not work correctly, consult your PBX supplier for the correct settings.

1 Press **[MENU]**.	
2 Scroll to "Initial setting" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).	Initial setting
3 Scroll to "Set tel line" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).	Set tel line
4 Scroll to "Set flash time" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).	Set flash time
5 Select the flash time by pressing **[▼]** or **[▲]**.	Set flash time :700ms
6 Press the soft key (SAVE), then press **[OFF]**.	

Incoming Call Tone Handset

During an intercom call (p. 37), you can be informed of incoming calls by two tones. If this feature is turned on, incoming call tones will be heard for as long as the line is ringing. If this feature is set to “2”, incoming call tones will be heard only 2 times. If this feature is turned off, no tones will be heard. This factory preset is “2”.

1 Press **[MENU]**.

2 Press the soft key (**SELECT**) at “Ringer setting”.

3 Scroll to “Incoming call ” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



4 Select “On”, “Off” or “2” by pressing **[▼]** or **[▲]**.



5 Press the soft key (**SAVE**), then press **[OFF]**.

Key Tone Handset

You can select whether or not the handset keys will sound tones (key tone, confirmation tone, error tone). The factory preset is ON.

1 Press **[MENU]**.

2 Scroll to “Initial setting” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



3 Scroll to “Key tone” by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

4 Select “Off” or “On” by pressing **[▼]** or **[▲]**.



5 Press the soft key (**SAVE**), then press **[OFF]**.

Belt Clip

You can hang the handset on your belt or pocket using the included belt clip.

To attach the belt clip **To remove the belt clip**



Optional Headset

Connecting an optional headset to the handset allows hands-free phone conversation. Please use only a Panasonic KX-TCA60, KX-TCA86, KX-TCA88, KX-TCA88HA, KX-TCA91, KX-TCA92, or KX-TCA98 headset. To order, call the accessories telephone number on page 2.

Connecting an optional headset

Open the headset jack cover, and insert the headset plug into the headset jack as shown below.

• Headset sold separately. Model shown here is KX-TCA88.

To switch to the speakerphone while using the headset:
Press **[ ]**. To return to the headset, press **[ ]**.

Wall Mounting

Base unit

This unit can be mounted on a wall phone plate.

1 Connect the AC adaptor.



Tuck the telephone line cord inside the wall mounting adaptor (❶).
Connect the telephone line cord (❷).



3 Insert the hooks on the wall mounting adaptor into the holes (Ⓐ) and (Ⓑ) on the base unit.

4 Adjust the adaptor to hold the base unit, then push it in the direction of the arrow until it clicks into place.





5 Connect the telephone line cord. Mount the unit, then slide it down.

• Raise the antennas.



6 **To charge the handset battery:**
Place the handset on the base unit.

• The unit beeps once and the CHARGE indicator lights.

Wall Mounting

To remove the wall mounting adaptor

While pushing down the RELEASE LEVERS (❶), remove the adaptor (❷).



Charger unit (KX-TG5202 only)

The charger can be wall mounted. Connect the AC adaptor. Install screws using the wall template (see below). Mount the charger (❶). Slide it down (❷), then slide down to the right (❸) until it is secured.







Wall Template for the Charger unit

Direct Commands

Handset

After pressing **[MENU]**, you can also program menu items directly by pressing (**[0]** to **[9]**, and **[#]**) instead of using the soft keys.

Menu item	Command	Selection items	Page
Ringer volume	**[1] [1]**	**[0]** : Off **[1]** : Low **[2]** : Medium **[3]** : High	p. 17
Ringer tone	**[1] [2]**	**[1]**–**[3]** : Tone pattern 1–3 **[4]**–**[7]** : Melody pattern 1–4 **[8]**–**[9]** : Downloaded melody pattern 1–2 *1	p. 18
Incoming call tone	**[1] [3]**	**[1]** : On **[2]** : Twice **[0]** : Off	p. 46
Voice enhancer	**[5]**	**[1]** : On **[0]** : Off	p. 22
Activate Caller IQ *2	**[7] [1]**		–
View information *4	**[7] [2]** *5	Go to Step 4 on page 64.	–
Get new information *3	**[7] [3]** *5	Go to Step 4 on page 63.	–
Turn Caller IQ off *3	**[7] [4]** *5		p. 61
Turn Caller IQ on *3	**[7] [5]** *5		p. 61
Copy phone book –Copy 1 item	**[#] [1]**	Go to Step 4 on page 35.	–
Copy phone book –Copy all items	**[#] [2]**	Go to Step 4 on page 36.	–
LCD contrast	**[0] [1]**	**[1]**–**[6]** : Level 1–6	p. 19
Key tone	**[0] [2]**	**[1]** : On **[0]** : Off	p. 46
Auto talk	**[0] [3]**	**[1]** : On **[0]** : Off	p. 16
Caller ID Number Auto Edit	**[0] [4]**	**[1]** : On **[0]** : Off	p. 28
Set dial mode	**[0] [5] [1]**	**[1]** : Pulse **[2]** : Tone	p. 15
Set flash time	**[0] [5] [2]**	**[1]** : 700 ms **[2]** : 600 ms **[3]** : 400 ms **[4]** : 300 ms **[5]** : 250 ms **[6]** : 110 ms **[7]** : 100 ms **[8]** : 90 ms	p. 45
Set line mode	**[0] [5] [3]**	**[1]** : A **[2]** : B	p. 16
Store VM access#	**[0] [7] [1]**	Go to Step 5 on page 40.	–
VM tone detect	**[0] [7] [2]**	**[1]** : On **[0]** : Off	p. 41
Change language	**[0] [8]**	**[1]** : English **[2]** : Spanish	p. 15

Menu item	Command	Selection items	Page
Message alert	**[0] [#]**	**[1]** : On **[0]** : Off	p. 19
Handset registration	**[0] [0] [1]**	Go to Step 5 on page 54.	–
Handset deregistration	**[0] [0] [2]**	**[3] [3] [5]**	p. 52

During programming:
When "SAVE" or "OK" is displayed, press the right soft key **to save the new settings**.
To exit programming, press **[OFF]**.

- If you press the direct command incorrectly, press **[OFF]**, then re-enter programming mode by pressing **[MENU]**.
- For function details, see the corresponding pages.

*1 You need to first download melody data from the openLCR web site.
*2 This feature can be used to activate Caller IQ. See the leaflet included with this unit for more information.
*3 For openLCR subscribers only.
*4 For openLCR subscribers only. If information is not downloaded to your unit, "Get new Info ?" will be displayed. To download information, see page 63.
*5 After pressing **[7]**, make sure "View Info ?" is displayed, then press the next command. If Caller IQ is turned off, "Turn CIQ on?" is displayed after pressing **[7]**.

Canceling Registration/Re-registration

Canceling the Handset Registration Handset

If you no longer need to use the handset or if you want to use the handset with a different base unit of the same model, it is necessary to cancel the handset's registration from the current base unit.
Only one handset can be canceled at a time.
Make sure the handset and the base unit near each other and are not being used.

1 Press **[MENU]**.

2 Scroll to "Initial setting" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).



3 Scroll to "Registration" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).



4 Scroll to "Deregistration" by pressing **[▼]** or **[▲]**, then press the soft key (SELECT).

5 Press **[3][3][5]** to delete the registration memory.
- If you enter a wrong code, re-enter **[3][3][5]**.



6 Press the soft key (**OK**).
- The registration memory will be erased on both the handset and the base unit.
- If the handset beeps 3 times, you entered a wrong code.
  Enter "335", then press the soft key (**OK**).
- To register the handset to another base unit of the same model, start from step 5 on page 54.

Ex. Extension number 2

- "[-]" is shown on the top right of the display.
- After canceling registration, the handset cannot be used. If you want to use it again, register the handset to the base unit by performing steps 5 and 6 on page 54.

Re-registering the Handset Handset & Base Unit

If you want to re-register the handset to the base unit or a different base unit of the same model, you need to register it to that base unit. The handset will be given a new extension number of that base unit. Only one handset can be registered at a time near the base unit. **Make sure the base unit and the other handsets are not being used. Have both the handset and base unit nearby during registration.**

If you have canceled handset registration at a previous base unit (p. 52), start from step 5 on page 54.

1 *Handset:* Press **[MENU]**.

2 *Handset:* Scroll to "Initial setting" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 *Handset:* Scroll to "Registration" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



4 *Handset:* Press the soft key (**SELECT**) at "HS registration".

seconds.
- The CHARGE indicator flashes. After the CHARGE indicator starts flashing, the rest of the procedure must be completed within 1 minute.

6 *Handset:*
(1) Press the soft key ( ).
(2) Wait until a long beep sounds and the display shows the new extension number (ex. extension number 2).
- Registration is complete.

- You can stop registration by pressing **[OFF]** on the handset and pressing **LOCATOR [ ]**, **[ ]**, **[ ]**, **[ ]** or **[ ]** on the base unit.
- If "`Wrong handset Refer to manual`" is displayed, the handset you tried to register is not for this base unit. This handset is for KX-TG6500 base unit. The accessory handsets for this base unit are KX-TGA520 and KX-TGA523. To order, see page 3.

If you have not canceled the handset's registration at the previous base unit (p. 52), the handset number remains in that base unit's memory. To erase the handset number from the previous base unit, see the base unit's Operating Instructions. For the KX-TG5200 or KX-TG5202 base unit: (1) Press and hold **LOCATOR [ ]** until the CHARGE indicator flashes, and (2) Press and hold **LOCATOR [ ]**, **[ ]**, **[ ]** or **[ ]** for the handset that you do not want until the CHARGE indicator flashes rapidly. When the indicator stops flashing, the handset number is erased.

If the Following Appear on Your Display...

The following will be displayed when the unit needs your attention.

Display message	Cause & Remedy
Recharge battery	• The battery needs to be charged. Recharge the battery (p. 12).
Charge for 6 HRS	• The battery has been discharged. The handset will not work. Fully charge the battery (p. 11).
No link to base Move closer to base and try again	• The handset has lost communication with the base unit. Walk closer to the base unit, and try again. • Confirm the base unit's AC adaptor is plugged in. • Raise the base unit antennas. • The handset's registration may have been canceled. Re-register the handset (p. 53, 54).
Please lift up and try again	• A handset button was pressed while the handset was on the base unit or charger (for KX-TG5202 or accessory handset users, p. 3). Lift the handset and press the button again.
Busy	• The called handset is in use. • Privacy mode is on for the call you tried to join (p. 43). • The handset you tried to send phone book items to is in use. • The handset you are calling is too far from the base unit.
Invalid	• The called handset has not been registered to the base unit. • You selected your own extension number.
Error!!	• When you tried to register or deregister the handset, the handset and base unit could not link for some reason, such as interference from electrical appliances. Move the handset and base unit away from any electrical appliances and try again. • If more than one handset is in use, you may not be able to register/deregister. Try again later. • Another handset tried to send phone book items to you but copying stopped. Have the other handset user re-send the items to you (p. 35, 36).
System is busy Please try again later	• If more than one other user is using the handset and/or base unit, such as conducting outside/intercom calls, you may not be able to use the handset. Try again later. • The handset has lost communication with the base unit. Walk closer to the base unit and try again.

If the Following Appear on Your Display...

Display message	Cause & Remedy
Phone book full	• When you tried to store an item in the phone book, the phone book memory was full. Press **[OFF]** to exit programming mode. To erase other items from the phone book, see page 34.
---Incomplete--- Tom Jones 098-765-4321 Phone book full (The name/number is an example.)	• When the displayed item was sent to the destination handset, the phone book memory was full and copying stopped. If you tried to send all of the items, the item displayed with "Incomplete" and items after it have not been copied to the destination handset. Press **[OFF]**

Troubleshooting

If the handset display shows error messages, see "If the Following Appear on Your Display..." (p. 55–56) for the Cause & Remedy.

Problem	Cause & Remedy
"No link to base Move closer to base and try again " is displayed and an alarm tone sounds.	• The handset has lost communication with the base unit. Walk closer to the base unit, and try again. • Confirm the base unit's AC adaptor is plugged in. • Raise the base unit antennas. • The handset's registration may have been canceled. Re-register the handset (p. 53, 54).
The handset and/or base unit does not work.	• Check the settings (p. 10–12). • Check whether the dialing mode setting is correct (p. 15). • Fully charge the battery (p. 11). • Clean the charge contacts and charge again (p. 12). • Check battery installation (p. 11). • Unplug the base unit's AC adaptor to reset it. Plug in, and try again. • The handset has not been registered to the base unit. Register the handset (p. 54, steps 5 and 6). • Re-install the battery (p. 11) and fully charge it.
Static, sound cuts in/out, fades. Interference from other electrical units.	• Move the handset and base unit away from other electrical appliances (p. 6). • Walk closer to the base unit. • Raise the base unit antennas. • Turn on the Clarity Booster feature (p. 22).
The handset does not ring.	• The ringer volume is turned off. Set to high, medium, or low (p. 17). • If more than one other user is using the handset, the handset may not ring. Users will hear incoming call tones (p. 46).
The handset display is blank.	• If the handset display is blank, fully charge the battery (p. 11).

Troubleshooting

Problem	Cause & Remedy
You cannot program any function items.	• Programming is not possible while the handset and/or base unit is being used. • Do not pause for over 60 seconds while programming. • Walk closer to the base unit.
While programming or searching, the handset starts to ring and the program/ search stops.	• A call is coming in. To answer the call, press **[ ]** or **[ ]**. Start again from the beginning after hanging up.
You cannot make an intercom/ outside call.	• If more than one other user is using the handset and/or base unit, you may not be able to make a call. Try again later. • The handset you called is too far from the base unit.
You cannot redial.	• If the last number dialed was more than 48 digits long, the number will not be redialed correctly.
You cannot make long distance calls.	• Please make sure you have long distance service. • Check if Caller IQ feature is turned on. Turn Caller IQ feature off (p. 61).
The handset does not display the caller's name and/or phone number.	• You need to subscribe to Caller ID. • Other telephone equipment may be interfering with your phone. Disconnect it and try again. • Other electrical appliances connected to the same outlet may be interfering with Caller ID. • Telephone line noise may be affecting Caller ID. • The caller requested not to send his/her Caller ID information (p. 24). • If a call is being transferred to you, the Caller ID information will not be displayed. • If a (separate) Caller ID box is connected between the base unit and the telephone wall jack, disconnect the Caller ID box or plug the unit directly into the wall jack.
The handset cannot automatically edit the Caller List/incoming phone numbers.	• The Caller ID Number Auto Edit feature is turned off. Turn it on (p. 28) and try again. • You need to press **[ ]** or **[ ]** after editing the number.

Problem	Cause & Remedy
The handset display exits the Caller List or phone book.	• Do not pause for over 60 seconds while searching.
"Recharge battery" is displayed, " " flashes, or the handset beeps intermittently.	• Fully charge the battery (p. 11).
"Charge for 6 HRS" and " " are displayed and the handset does not work.	• The battery has been discharged. Fully charge the battery (p. 12).
You charged the battery fully, but "Recharge battery" is still displayed and/or " " continues to flash, or "Charge for 6 HRS" and " " are displayed.	• Clean the charge contacts and charge again (p. 12). • The battery may need to be replaced. If you install a new battery, fully charge it (p. 11, 12).
The CHARGE indicator does not go out after the battery has been charged.	• This is normal.
The Ringer/Message Alert indicator flashes slowly when the handset is not ringing and in use.	• The Message Alert is turned on and new messages in your voice mailbox have been recorded. Turn the Message Alert off (p. 19) or listen to the new messages (p. 42).
You cannot have a conversation using the headset.	• Make sure the optional headset is connected properly (p. 47). • If "SP-phone" is displayed on the handset, press **[ ]** to switch to the headset.
If you cannot solve your problem	• Visit our website: http://www.panasonic.com/support • Contact us via the web at: http://www.panasonic.com/contactinfo • Call our customer call center at: 1-800-211-PANA(7262)

openLCR service for Caller IQ

Problem	Cause & Remedy
When you try to download the data from openLCR, the voice prompt is not announced from the handset while "`Listen & follow phone guidance`" is being displayed.	• Check the settings (p. 10–12). • Dialing to openLCR may have been disconnected. Try again (p. 63). • If you cannot solve a problem, consult openLCR (see below).
For more information about Caller IQ	• Call openLCR's customer service department at 1-866-openLCR(1-866-673-6527). • openLCR's web site: www.openLCR.com

openLCR Service for Caller ID

The unit is compatible with services provided by openLCR.

Important:

- **If you have any questions regarding the openLCR service, call openLCR's customer service department at 1-866-openLCR(1-866-673-6527).**
- NEITHER PANASONIC COMMUNICATIONS CO., LTD. (PCC) NOR MATSUSHITA ELECTRIC CORPORATION OF AMERICA (MECA) IS IN ANY WAY AFFILIATED WITH, OR RESPONSIBLE FOR THE ACTS OR OMISSIONS OF, OPENLCR.COM, INC. (OPENLCR). NEITHER PCC NOR MECA NOR ANY OF THEIR EMPLOYEES OR AFFILIATES OR CUSTOMERS MAKE ANY WARRANTIES OR REPRESENTATIONS, EITHER EXPRESS OR IMPLIED, TO ANY CUSTOMER OR ANY OTHER THIRD PARTY WITH RESPECT TO ANY OF THE SERVICES PROVIDED BY OPENLCR, NOR ASSUME NOR CREATE ANY OTHER OBLIGATION OF ANY KIND ON BEHALF OF OPENLCR.

Turning on or off Caller ID Feature Handset

After the first download to your phone, Caller ID features are automatically turned on. If you wish, you can turn off Caller ID.

• When Caller ID is on, "【CID】" is displayed while talking.

To turn off Caller ID feature (when it is already on.)

1 Press **[MENU]**.

2 Scroll to "Caller ID" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).



3 Scroll to "Turn CID off?" by pressing **[▼]** or **[▲]**, then press the soft key (**YES**).

• "Caller ID off" is displayed.



4 Press **[OFF]**.

To turn on Caller ID feature (after it was turned off)

1 Follow steps 1 to 2 of "To turn off Caller ID feature" above.

2 Press the soft key (**YES**) at "Turn CID on?".

• "Caller ID on" is displayed.



3 Press **[OFF]**.

• If you turn on or off the Caller ID feature using one of the handsets, you will not need to turn on or off using another handset.

Downloading Data

You can download the following data to your unit from the openLCR web site.

- Phone book data
- Ringer melodies (Custom ringtone)
- Function setup for your unit
- Information such as weather forecasts, stock quotes, lottery results, sports scores and horoscopes (Internet content)

Accessing the openLCR web site can be done from any computer with Internet access.

To create data on the openLCR web site

1 Access the openLCR's web site at **www.openLCR.com** and click on the "Manage Account/Login" tab.

2 Enter your Telephone Number and Password, then click Accept.

3 Follow the on-screen instructions.

Phone book data:

- To create the phone book data, enter a name of up to 16 characters, and a phone number of up to 32 digits.
- If you have already stored items into the phone book of the unit, you need to enter all of those stored items again using the openLCR web site. Then add all new items through the openLCR web site.

Ringer melodies:

- The unit stores up to 2 ringer melodies in the handset and you can select up to 2 ringer melodies as ringer tone (p. 51, 64).

Function setup:

- See openLCR's web site for function items available for download.

Information:

- You can select the information which you want to show on the handset display.

- If you have stored items in the phone book of the unit, you also need to store those items on the web site.
- The description on the openLCR web screen is subject to change without notice.

To download data from openLCR Handset

Each time you download data (p. 62) from openLCR, the information stored in your unit will be updated. To view up-to-date information, you will need to download it to your unit.

- You can select the items of information on the web site which you want to view.
- Each handset can download its own data only.
- Horoscopes are for entertainment purposes only.

1 Press **[MENU]**.

2 Scroll to "Caller IQ" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

3 Scroll to "Get new Info ?" by pressing **[▼]** or **[▲]**, then press the soft key (**YES**).

- The unit will dial openLCR automatically.
- A voice prompt will be heard.

If you live in or move from another area to Fort Collins, Colorado, press **[#]** before pressing the soft key (**YES**).



4 Follow the voice prompt to start downloading.

- If you have rotary or pulse service, you need to press **[✳]** to change the dialing mode temporarily to tone, before following the voice prompt.
- When downloading starts, the display will show the message on the right.
- After downloading starts, the handset must be off-hook. DO NOT PLACE the handset on the base unit or charger (for KX-TG5202 or accessory handset users, p. 3). Placing the handset on the base unit or charger will terminate the download process. DO NOT PRESS **[OFF]** (pressing **[OFF]** will terminate the download process).



5 When downloading is complete, a beep sounds.



- You can also go to the Caller IQ menu after pressing **[↷]** or **[📖]**. Press **[MENU]**, then **[3]** to select "3=Caller IQ". Follow steps 3 to 5 above.
- If the handset beeps 3 times and the following is displayed, the unit has lost communication with openLCR. Store items by following the steps below.



1. Access the openLCR web site.
2. Go to the web screen to create the data.
   - To download the phone book data, click Re-Download All. Then go to step 3.
3. Start again from step 1 ("To download data from openLCR").

- If the handset beeps 3 times and the following is displayed, some items could not be stored in the phone book. Store items by following the steps below.

```
Download
incomplete
Phone book full
```

  1. Erase items which do not exist on the web from the phone book of the unit (p. 34).
  2. Access the openLCR web site.
  3. Go to the web screen to create the phone book data.
  4. Click Re-Download All.
  5. Start again from step 1 ("To download data from openLCR" on page 63).
- You cannot access the openLCR server if a telephone or fax machine on the same phone line is in use simultaneously.
- While the unit is downloading data from openLCR, the Call Waiting Service cannot be used.

To use downloaded melodies as the ringer tone

The melody(ies) you download from openLCR are stored in the handset and will be heard when you receive an outside call. The names of each melody (up to 14 characters) are also downloaded.

To select the desired melody, go to the Ringer tone menu in the Ringer setting menu (p. 18). Downloaded melody 1 and 2 can also be selected by pressing **[▼]**, **[▲]**, **[8]** or **[9]**.

To view information

1 Press **[MENU]**.

2 Scroll to "Caller IQ" by pressing **[▼]** or **[▲]**, then press the soft key (**SELECT**).

```
Caller IQ
```

3 Press the soft key (**YES**) at "View Info ?".

```
View Info ?
```

- The items of information which you selected on the web are displayed.
- If information is not downloaded to your unit, "Get new Info ?" will be displayed. To download information, see page 63.

4 Scroll to the desired information by pressing **[▼]** or **[▲]**.

- You can also select the desired information by pressing dialing buttons.

5 When finished, press **[OFF]** or place the handset on the base unit or charger.

Important Safety Instructions

When using this unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or personal injury.

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on this unit.
3. Unplug this unit from AC outlets before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this unit near water, for example, near a bathtub, washbowl, kitchen sink, or the like.
5. Place this unit securely on a stable surface. Serious damage and/or injury may result if the unit falls.
6. Do not cover slots and openings on the unit. They are provided for ventilation and protection against overheating. Never place the unit near radiators, or in a place where proper ventilation is not provided.
7. Use only the power source marked on the unit. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
8. Do not place objects on the power cord. Install the unit where no one can step or trip on the cord.
9. Do not overload wall outlets and extension cords. This can result in the risk of fire or electric shock.
10. Never push any objects through slots in this unit. This may result in the risk of fire or electric shock. Never spill any liquid on the unit.
11. To reduce the risk of electric shock, do not disassemble this unit. Take the unit to an authorized servicenter when service is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the unit is subsequently used.
12. Unplug this unit from the wall outlet and refer servicing to an authorized servicenter when the following conditions occur:
    A. When the power supply cord or plug is damaged or frayed.
    B. If liquid has been spilled into the unit.
    C. If the unit has been exposed to rain or water.
    D. If the unit does not work normally by following the operating instructions. Adjust only controls covered by the operating instructions. Improper adjustment may require extensive work by an authorized servicenter.
    E. If the unit has been dropped or physically damaged.
    F. If the unit exhibits a distinct change in performance.
13. During thunderstorms, avoid using telephones except cordless types. There may be a remote risk of an electric shock from lightning.
14. Do not use this unit to report a gas leak, when in the vicinity of the leak.

SAVE THESE INSTRUCTIONS

Important Safety Instructions

CAUTION:

To reduce the risk of fire or injury to persons, read and follow these instructions.

1. Use only the battery(ies) specified.
2. Do not dispose of the battery(ies) in a fire. They may explode. Check with local waste management codes for special disposal instructions.
3. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
4. Exercise care in handling batteries in order not to short the battery to conductive materials such as rings, bracelets, and keys. The battery and/or conductor may overheat and cause burns.
5. Charge the battery(ies) provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

- The AC adaptor is used as the main disconnect device, ensure that the AC outlet is located/installed near the unit and is easily accessible.

FCC and Other Information

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:ACJ-----.
If requested, this number must be provided to the telephone company.

Registration No. .....(found on the bottom of the unit)
Ringer Equivalence No. (REN) 0.1B

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3).

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please contact a Factory Servicenter or other Authorized Servicer. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

WHEN PROGRAMMING EMERGENCY NUMBERS AND(OR) MAKING TEST CALLS TO EMERGENCY NUMBERS:
1) Remain on the line and briefly explain to the dispatcher the reason for the call.
2) Perform such activities in the off-peak hours, such as early morning or late evenings.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this phone.

FCC and Other Information

CAUTION:
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference is experienced, move the cordless telephone further away from the TV or VCR. This will often reduce, or eliminate, interference.

Operating near 5.8GHz electrical appliances may cause interference. Move away from the electrical appliances.

FCC RF Exposure Warning:
This product complies with FCC radiation exposure limits set forth for an uncontrolled environment. To comply with FCC RF exposure requirements the base unit must be installed and operated with its antenna located 20 cm or more between antenna and all person's body (excluding extremities of hands, wrist and feet). The handset unit may be carried and operated with only the specific provided belt-clip. Other non-tested belt-clips or similar body-worn accessories may not comply and must be avoided. The base and handset units must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment is hearing aid compatible as defined by the FCC in 47 CFR Section 68.316.

When you hold the phone to your ear, noise might be heard in your Hearing Aid. Some Hearing Aids are not adequately shielded from external RF (radio frequency) energy. If noise occurs, use an optional headset accessory or the speakerphone option (if applicable) when using this phone. Consult your audiologist or Hearing Aid manufacturer about the availability of Hearing Aids which provide adequate shielding to RF energy commonly emitted by digital devices.

A TIA/EIA-IS-968 compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack that is also TIA/EIA-IS-968 compliant.

The software contained in this equipment to allow user access to the network must be ungraded to recognize newly established network area codes and exchange codes as they are placed into service.

Failure to upgrade the premises systems or peripheral equipment to recognize the new codes as they are established will restrict the customer and the customer's employees from gaining access to the network and to these codes.

- **Environment** — do not place the unit in a room where the temperature is less than 5°C (41°F) or greater than 40°C (104°F). Allow 10 cm (4") clearance around the unit for proper ventilation. Avoid excessive smoke, dust, mechanical vibration, shock, or direct sunlight.
- **Medical** — consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. (The unit operates in the frequency range of 5760MHz to 5840MHz, and the power output level can range 0.25 to 0.5 watts.) Do not use the unit in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF (radio frequency) energy.
- **Routine care** — wipe the unit with a soft cloth. Do not use benzine, thinner, or any abrasive powder. When you leave the unit unused for a long period of time, unplug the AC adaptor from the outlet.
- **If there is any trouble** — disconnect the unit from the telephone line and connect a known working phone. If the known working phone operates properly, have your unit repaired by one of the authorized Panasonic Factory Service Centers. If the known working phone does not operate properly, consult your telephone company.

Specifications

■ **Handset**

Power Supply:	Ni-MH battery (3.6 V, 830 mAh)
Frequency:	5.76 GHz – 5.84 GHz
Dimensions (H x W x D):	Approx. 220 mm x 53 mm x 37 mm ($8\ ^{21}/_{32}$" x $2\ ^{3}/_{32}$" x $1\ ^{15}/_{32}$")
Mass (Weight):	Approx. 210 g (0.46 lb.)
Security Codes:	1,000,000

■ **Base Unit**

Power Supply:	AC adaptor (120 V AC, 60 Hz)
Power Consumption:	Standby: Approx. 2.3 W Maximum: Approx. 5.5 W
Frequency:	5.76 GHz – 5.84 GHz
Dimensions (H x W x D):	Approx. 107 mm x 214 mm x 135 mm ($4\ ^{7}/_{32}$" x $8\ ^{15}/_{32}$" x $5\ ^{5}/_{16}$")
Mass (Weight):	Approx. 340 g (0.75 lb.)

■ **Charger (KX-TG5202 only)**

Power Supply:	AC adaptor (120 V AC, 60 Hz)
Power Consumption:	Standby: Approx. 0.8 W Maximum: Approx. 4.0 W
Dimensions (H x W x D):	Approx. 69 mm x 74 mm x 100 mm ($2\ ^{23}/_{32}$" x $2\ ^{29}/_{32}$" x $3\ ^{15}/_{16}$")
Mass (Weight):	Approx. 120 g (0.28 lb.)

■ **Dialing Mode:** Tone (DTMF)/Pulse

■ **Operating Environment:** 5 °C – 40 °C (41 °F – 104 °F)

Specifications are subject to change without notice.

Energy Star:

As an ENERGY STAR® Participant, Panasonic has determined that this product meets the ENERGY STAR guidelines for energy efficiency. ENERGY STAR is a U.S. registered mark.

Index

A

Accessories 2
Accessory handset 3
Answering calls 23
Auto talk 16, 23, 37

B

Backlit LCD 22
Base unit location 6
Battery charge 6, 11
– *Battery information 12*
Battery replacement 11, 12
Battery strength 11
Belt clip 47
– *Booster 22*

C

Call share 39
Call Waiting Caller ID display 44
Call waiting tone 44
– *Caller ID number auto edit . . 27, 28*
Caller ID service 24
Caller IQ 61
Caller List, editing 27
Caller List, erasing 29
Caller List, storing 29
Caller List, viewing 25
Calling back from the Caller List . . 26
– *Chain dial 33*
CID (Caller ID) 24
– *Clarity booster 22*
CONF (Conference) 39
Conference calls 39
– *Copy phone book 35*

D

Deregistration 52
Dialing mode 15
Direct commands 51, 52
Display 9
Display language 15

E

Error messages 55
Extension number 37, 53, 54

F

FCC and other information 67
FLASH button 45
Flash time 45
– *Function menu, Direct commands 51, 52*
Function menu, selection 13
Function menu, table 14

H

Handset locator 43
Headset, optional 47
Hold 21

I

Incoming call tone 46
Installation, AC adaptor 10
Installation, battery 11
Installation, charger unit 10
Installation, telephone line cord . . . 10
Intercom call 37

K

Key tone 46

L

LCD contrast 19
Lighted handset keypad 22
Line mode 16
Location of controls 7, 8

M

Making calls 20
– *Message alert 19*
Microphone, handset 20
Mute 43

N

Navigator key 8
Noise 6

O

openLCR 61

Index

P

PAUSE 45
– *Phone book* *30*
– *Phone book, copying* *35, 36*
Phone book, dialing 32, 33
Phone book, downloading 62
Phone book, editing 34
Phone book, erasing 34
Phone book, names 31
Phone book, storing 30
Power failure 10
Privacy feature 43
Pulse service 44

R

Redial 21
Redial list 21
– *Registration* *53*, *54*
Registration, canceling 52
Ringer off 17, 23
Ringer tone 18
Ringer volume 17
Rotary service, tone dialing 44

S

Safety instructions 65
Shipping product for service . . . . . Back cover
Soft keys 8
Specifications 70
SP-phone 20

T

– *Transferring a call* *38*
Troubleshooting 57
TTY . . . . . 2, 74, Back Cover

V

VE (Voice Enhancer) 22
– *VM (Voice Mail)* *40*
– *Voice enhancer technology* *22*
Volume control, handset 21

W

Wall mounting 48
Warranty 73

• "–" indicates important information and frequently used features.

es do not allow the exclusion or limitation of incidental or consequential damages,
ns on how long an implied warranty lasts, s

For product service

- Visit our website: http://www.panasonic.com/support
- Contact us via the web at: http://www.panasonic.com/contactinfo
- Call us at: 1-800-211-PANA(7262)

When you ship the product

- Carefully pack your unit, preferably in the original carton.
- Attach a letter, detailing the symptom, to the outside of the carton.

Symptom

- Send the unit to an authorized servicenter, prepaid and adequately insured.
- Do not send your unit to the Panasonic Consumer Electronics Company listed below or to executive or regional sales offices. These locations do not repair consumer products.

For your future reference

Serial No. Date of purchase

(found on the bottom of the unit)

Name and address of dealer

- This cordless telephone is designed for use in the United States of America. Sale or use of this product in other countries may violate local laws.
- Ce téléphone sans fil est conçu pour être utilisé aux États-Unis d'Amérique. La vente ou l'emploi de cet appareil dans certains autres pays peut constituer une infraction à la législation locale.
- Este teléfono inalámbrico fue elaborado para uso en los Estados Unidos de América. La venta o el empleo de este producto en ciertos países puede constituir violación de la legislación local.
- このコードレス電話機は、日本国外での使用を目的として設計されており、日本国内での使用は法律違反となります。従って、当社では日本国内においては原則として修理などのサービスは致しかねます。

If you need assistance with setup or operation, please call 1-800-211-PANA(7262)
For hearing or speech impaired TTY users, TTY : 1-877-833-8855

Panasonic Consumer Electronics Company,
Division of Matsushita Electric Corporation of America
One Panasonic Way, Secaucus, New Jersey 07094

Panasonic Sales Company,
Division of Matsushita Electric of Puerto Rico, Inc.
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park
Carolina, Puerto Rico 00985

© 2004 Panasonic Communications Co., Ltd. All Rights Reserved.

PQQX13998ZA S0104-0